

Welcome to Hiwatt.

Proudly producing generations of Iconic British Tone for the World's best artists. Legendary headroom, clean and clear sounds, great for pedals and studio work, unbeatable live onstage.



AMPLIFIER FEATURES*

- Small form factor and a variety of colour options.
- Aux in and wireless capabilities to play along to your favourite songs.
- Simple but highly useable tone stack.
- Headphone out for silent practices.





Please read these instructions carefully before switching your amplifier on.

- Please ensure that the voltage selector/ indicator and fuses match the supply voltage of the country in which the amplifier is being used.
- Do not switch the amplifier on without the loudspeaker connected. It is important that the amplifier and speaker are matched at the correct impedance. Failure to do so can result in damage to the amplifier or speaker.
- Never attempt to by-pass fuses or fit ones of incorrect value.
- Never use an amplifier in wet or damp conditions.
- Protect the power cord from being walked on or pinched. Do not modify.

- All servicing should be carried out by a professionally qualified service technician.
- Always ensure free movement of air around the amplifier to prevent overheating.
- Do not attempt to remove the amplifier chassis, there are no user serviceable parts inside.
- Always use the supplied mains lead provided with your amplifier. If a replacement is needed, please contact your Hiwatt Dealer.
- Always unplug this amplifier during lightning storms or when unused for prolonged periods of time.

WARNING – if used improperly or without proper safeguards this equipment can cause hearing damage or loss of hearing.

Servicing is required when the apparatus has been damaged in any way, such as when the power supply or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally or has been dropped.





Follow all instructions and warnings

Please keep instructions in a safe place Register product online: **Hiwatt.co.uk**

LONDON 12







FRONT PANEL FEATURES



Input - Plug your instrument in here with a 1/4" instrument cable.

Volume - This controls the volume level of the amp.

Gain - (London 12) This controls the level of gain applied to the input.

Overdrive - (London 10) This button toggles the overdrive channel on and off.

Bass - Adjusts the level of low frequency.

Treble - Adjusts the level of high frequency.

Aux - Plug in an external audio device here with a 3.5mm jack.

Headphone Out - Plug in headphones with a 3.5mm jack.

Wireless Connection - Press black button to turn on. Blue LED will flash when searching for a media device to pair. Blue LED will stop flashing when successfully paired.

REAR PANEL FEATURES



12V DC Input - Connect with correct Hiwatt power adapter. **Power** - Connect with the correct Hiwatt power adapter.

TURNING ON YOUR AMPLIFIER

- Plug in the included 12V DC grounded adapter.
- Set VOLUME to zero.
- Set **BASS** and **TREBLE** knobs to 12 o'clock.
- Plug your instrument into the INPUT using a 1/4" instrument cable.
- Turn the amplifier on. Set VOLUME to desired volume level.
- Boost or cut **BASS** and **TREBLE** to taste.

GETTING CREATIVE WITH TONES

Clean and Clear

VOLUME - Set Volume to maximum **Gain** - Set Gain to zero **EQ** - Boost Bass and Treble

Low-Gain Grit

VOLUME - Set Volume to maximum Gain - Set Gain to 9 o'clock EQ - Boost Treble

INPUT VOLUME GAIN BASS TREBLE



Heavy Distortion

VOLUME - Set Volume to desired level Gain - Set Gain from 3 o'clock to maximum EQ - Cut Bass and set Treble to taste

Clean to Distortion

VOLUME - Set Volume to desired level Gain - Set Gain from 3 o'clock to maximum EQ - Cut Bass and set Treble to taste





Toggle between clean and distorted tones using the Overdrive button





HIWATT



- Hiwatt amplifiers are warranted against defects in materials and worksmanship for a period of 1 year.
- Speakers, transformers, reverb tank, batteries, and tubes/valves for 90 days.
- Please note: It is your responsibility to use the equiptment safely and properly without modifications, within specifications and with a safe power supply.
- Please note: The limited Warranty provided is non-transferable. (please register your product online

and retain sales receipt and original packaging) and authorization needs to be obtained

by Hiwatt Electronics (Hiwatt.co.uk) before any service work is completed by a professionally qualified Service Technician

• Shipping costs incurred obtaining warranty service are the responsibility of the purchaser, and the

purchaser must obtain permission to ship any/allproduct prior to shipping.

• Please note: Any damages incurred in shipping must be reported to the shipper and Hiwatt Electronics immediately upon recieving the product.

Follow all instructions and warnings

Please keep instructions in a safe place Register product online: **Hiwatt.co.uk**

Serial Number:

Date of Purchase:

Store Contact Info:

John 1



Hiwatt Electronics Limited

Unit 3, Plumb Units, Sandall Stones Road Kirk Sandall, Doncaster DN3 1QR

SALES@HIWATT.CO.UK

