Park 45/50/75 manual

Welcome to Park Amplification and thank you for becoming part of the Park family. Park Amplification makes some of the finest vintage-style, British-design tube guitar amplifiers. The Park 45, 50 and 75 are newly manufactured amps that recreate the sound and feel of the amps made from 1965 to the mid 1970s. We use the best modern and vintage components to recreate the tone that made these amps some of the most collectible and coveted by tone aficionados and collectors alike.

In order to achieve the goal of consistent superior vintage Park tone, we have built sourced superior transformers and selected the best currently available resistors, capacitors, circuit boards and tubes. Park amps are built one at a time in New York by skilled amp builders to the absolute highest quality standards. Each amplifier is thoroughly burned-in and tested for function and tone before leaving the workshop.

Front Panel

There are two channels which are voiced differently. The channel on the right is warmer and has less treble. The one on the left is brighter and more aggressive. There are two inputs per channel. The top jack input is the one that is usually plugged into and has more gain than the lower input. There is one Volume control for each channel. The other controls all adjust tone and are Treble, Mid, Bass and Brightness (Presence). Other things on the front panel include the On/Off switch, Standby switch and Mains fuse (2 or 3 Amp, slo blo, see below for specific model).

There are a number of useful ways to plug into a "four-hole" amp.

- 1) Plug into either top jack and use its associated Volume control. Adjust the tone controls to taste.
- 2) Plug into the top input of the left (bright) channel and plug a short jumper cable from the lower input of the left channel into the top input of the right channel. You are now plugged into both channels and can blend them for more tonal possibilities. This setup is commonly used on the more aggressive 1970s amps where the left input has very little bass (until you crank it all the way up) and the right Volume control is used to fatten the sound. The left channel on this amp is full with plenty of bass so this is not necessary but you can if you like!
- 3) Plug into the top input of the right channel, turn it up to the desired level (louder is usually better!) and then turn up the Volume control of the left channel to add some highs (chirp) and upper mids. The setting of the left Volume control will vary depending on the speakers, room conditions and anything else that can affect tone. This is a favorite arrangement for the early two-channel, four-hole amps which used a shared cathode on the first 12AX7. It is rumored that some famous guitarists used this setup to achieve their sound in the mid to late 1960s.

This is a simple, plug-and-play amp. Plug in, set your controls and play some music!

Back Panel

HT fuse (0.5 Amp, slo blo)

IEC AC Mains connector

Voltage selector (some versions do not have this)

Impedance selector (4, 8, 16 ohms)

Speaker jacks: Set the impedance to the same impedance rating of your speaker cabinet. The combo comes with two 16 ohms speakers in parallel which equals 8 ohms.

Specifications

Park 45

Power: 30 watts clean, 45 watts when pushed

Tubes: two KT66s, three 12AX7s

Front panel: Volume (ch1), Volume (ch2), Treble, Mid, Bass, Brightness, On/Off, Standby, Mains Fuse (2A or 3A, slo-blo)

Back panel: HT fuse (500mA), IEC mains (AC) socket, optional Voltage selector, Impedance selector (4, 8, 16), two speaker outputs

Dimensions: (H) 10", (W) 24", (D) 8.375"

Weight: 31 lbs

Park 45 Combo Specifications

Power: 30 watts clean, 45 watts when pushed

Tubes: two KT66s, three 12AX7s

Front panel: Volume (ch1), Volume (ch2), Treble, Mid, Bass, Brightness, On/Off, Standby, Mains Fuse (2A or 3A, slo-blo)

Back panel: HT fuse (500mA), IEC mains (AC) socket, optional Voltage selector, Impedance selector (4, 8, 16), two speaker outputs

Speakers: Two Celestion Heritage G12M 16 ohm speakers wired in parallel for a total of 8 ohms

Dimensions: (H) 19.75", (W) 28", (D) 10.5"

Weight: 49 lbs

Park 50

Power: 50 watts clean, 70 when pushed

Tubes: two EL34s, three 12AX7s

Front panel: Volume (ch1), Volume (ch2), Treble, Mid, Bass, Brightness, On/Off, Standby, Mains Fuse (2A

or 3A, slo-blo)

Back panel: HT fuse (500mA), IEC mains (AC) socket, optional Voltage selector, Impedance selector (4, 8,

16), two speaker outputs

Dimensions: (H) 10", (W) 24", (D) 8.375"

Weight: 31 lbs

Park 50 Combo Specifications

Power: 50 watts clean, 70 watts when pushed

Tubes: two EL34s, three 12AX7s

Front panel: Volume (ch1), Volume (ch2), Treble, Mid, Bass, Brightness, On/Off, Standby, Mains Fuse (2A

or 3A, slo-blo)

Back panel: HT fuse (500mA), IEC mains (AC) socket, optional Voltage selector, Impedance selector (4, 8,

16), two speaker outputs

Speakers: Two Celestion Heritage G12H 16 ohm speakers wired in parallel for a total of 8 ohms

Dimensions: (H) 19.75", (W) 28", (D) 10.5"

Weight: 49 lbs

Park 75

Power: 50 watts clean, 90 when pushed

Tubes: two KT88s, three 12AX7s

Front panel: Volume (ch1), Volume (ch2), Treble, Mid, Bass, Brightness, On/Off, Standby, Mains Fuse (3A

slo-blo)

Back panel: HT fuse (500mA), IEC mains (AC) socket, Voltage selector, Impedance selector (4, 8, 16), two

speaker outputs

Dimensions: (H) 10", (W) 24", (D) 8.375"

Weight: 32 lbs

Park 75 Combo Specifications

Power: 50 watts clean, 75 watts when pushed

Tubes: two KT88s, three 12AX7s

Front panel: Volume (ch1), Volume (ch2), Treble, Mid, Bass, Brightness, On/Off, Standby, Mains Fuse (3A

slo-blo)

Back panel: HT fuse (500mA), IEC mains (AC) socket, Voltage selector, Impedance selector (4, 8, 16), two

speaker outputs

Speakers: Two Celestion Heritage G12H 16 ohm speakers wired in parallel for a total of 8 ohms

Dimensions: (H) 19.75", (W) 28", (D) 10.5"

Weight: 50 lbs

Service: These amps are equipped with two fuses. One is on the front panel labeled "2 Amps". This is a historically correct designation since the original amps were made for the UK market. When used with 120 Volts a 3 Amp fuse (slo blo) is recommended. There is also a back panel fuse labeled either 500mA or 1A. While either can be used, 500mA is recommended. If your amp is blowing fuses, something may be wrong and it is highly recommended that you bring the amp to a qualified technician who is familiar with tubes and guitar amps.

Tubes have a life span and can wear out over time. Power tubes (KT66, EL34 or KT88) typically will wear out faster than preamp tubes (12AX7). If the power tubes are worn out your amp will sound lifeless and may lack power. Replacing tubes may seem easy but it is highly recommended that the amp be biased by a qualified technician.

Park Amplification

sales@parkamplifiers.co.uk parkamplifiers.co.uk

NON TRANSFERABLE 2-YEAR LIMITED WARRANTY

Britampco Ltd. warrants that the Park Custom Shop product you have purchased shall be free of any defects in parts and workmanship if used under normal operating conditions for a period of two (2) years from the date of purchase, except that pedals, footswitches and speakers are warranted for a period of one (1) year from date of purchase and light bulbs, vacuum tubes, cables and all other included accessory products are warranted for a period of ninety (90) days from date of purchase. This warranty shall run to the original purchaser when purchased from an Authorized Park Dealer or direct from Britampco LTD. IMPORTANT: PLEASE RETAIN YOUR SALES RECEIPT, AS IT IS YOUR PROOF OF PURCHASE COVERING YOUR LIMITED WARRANTY. THIS LIMITED WARRANTY IS VOID WITHOUT SUCH ENDORSED SALES RECEIPT.

Defective products that qualify for coverage under this warranty will be repaired without charge. If repair is not possible the product will be replaced at Britampco Ltd's discretion. To receive warranty service, email us at sales@parkamplifiers.co.uk for instructions which may include either returning the amplifier back to Britampco Ltd or sending the complete product to an Authorized Electronics Service Center, with proof of purchase, during the applicable warranty period. The Authorized Dealer from whom you purchased your product may also be authorized for warranty service. TRANSPORTATION COSTS ARE NOT INCLUDED IN THIS LIMITED WARRANTY.

Any repair or service performed by any person or entity other than an Authorized Electronics Service Center is not covered by this limited warranty. This limited warranty becomes void if the serial number on any product is defaced or removed, or the product has been damaged by alteration, misuse, accident, or neglect; or the product has been repaired or serviced by persons not authorized..

THE FOREGOING CONSTITUTES THE ONLY WARRANTY MADE BY Britampco Itd WITH RESPECT TO THE PRODUCTS AND IS MADE EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES EXPRESS OR IMPLIED. Any implied warranties, including without limitation, any implied warranties of merchantability or fitness for any particular purpose, imposed under state law are limited to the duration of this limited warranty. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not be applicable to you.

Britampco Ltd ASSUMES NO LIABILITY FOR PROPERTY DAMAGE RESULTING FROM FAILURE OF THIS PRODUCT NOR ANY LOSS OF INCOME, SATISFACTION, OR DAMAGES ARISING FROM THE LOSS OF USE OF SAME DUE TO DEFECTS OR AVAILABILITY OF SAME DURING SERVICE.